

Thank you for choosing Smartpay

Getting Started Guide | Smartpay PAX D200

The **D200** provides a small footprint, secure and robust mobile payment terminal. It requires a Wi-Fi connection and a compatible integrated point of sale (POS).

Complete these simple steps to get your terminal connected, ready for business.

STEP ONE: Switch on

Turn on the terminal by holding the  button on top of the terminal. The terminal will go through a start up sequence.




STEP TWO: Connect to the Wi-Fi

Terminal will attempt to connect to last Wi-Fi network. Make sure the terminal is in range of your Wi-Fi network, you will be prompted to connect/configure a network connection.

1. Press **CLEAR** to change your Wi-Fi network
2. Press **ENTER** to scan for network connections
3. Select the Wi-Fi network you wish to connect to
4. Enter the Wi-Fi password

If successful, the  icon lights up in the top left corner of the screen.

What's in the box*

		
D200 Terminal unit	Micro USB charger and cable*	Return courier label

MICRO USB

*If this is a replacement terminal you may need to use the cables from your existing terminal.

STEP THREE: Connect to the Paymark network

You terminal should be already connected, however if you are replacing an existing terminal you'll need to call us before you can transact. Call the Smartpay Technical Support Team on **0800 476 278**. We will release the security keys and perform your initial login.

STEP FOUR: Integrate with a POS

Your terminal will require a supported integrated POS system. You can download either Till2Go or ASB Pi.

1. Download your preferred supported integrated POS system.
2. Connect the supported POS to your terminal
(Please refer to the integration guide relevant to you, the guide can be found at smartpay.co.nz/guides)

Charging the terminal

You can charge the terminal by plugging it into the mains power. It will take approx. 3 hours for a full charge. It can also be charged using standard USB car charger accessory or spare batteries are available depending on your needs.

You can purchase these through our online store smartpay.co.nz/store.



To download the full user guide visit smartpay.co.nz/guides. This contains instructions on care for your terminal and full functionality details.

Key Buttons



Need help?

Get help online at: smartpay.co.nz/help

View the full user guide for your terminal at: smartpay.co.nz/guides

Call our Technical Helpdesk on **0800 476 278**

Contact your bank to enable/disable card types or contactless.

Contact Paymark to change your business name on your EFTPOS receipt.